

## Installation Instructions

1. Support truck by lower control arms.
2. Remove the tire and wheel assembly to gain access to the upper control arm mounting area.
3. Remove OEM control arm mounting bolts and washers.  
NOTE: Replace one upper control arm bolt assembly at a time.
4. Install thrust washer on cam bolt so that it is in between the mount and the cam washer.
5. Install camber/caster adjuster cam bolt.
6. Install a second thrust washer onto cam bolt.
7. Install cam washer, lock washer, and nut. Tighten slightly.
8. Repeat steps 3 thru 7 for other upper control arm bolts.
9. Adjust the camber by rotating the cams within the frame mounting brackets, 3/8 ratchet may be used in the square hole to rotate cams.
10. Torque the cam nuts to 80-100 ft. lbs.
11. Reinstall the wheel and road test.

