

Instructions for GM E-Body cars & S-10 Blazers and pickups.

Installation Location: Upper control arm mounting bolts.

Installation note: Replace one cam bolt assembly of each control arm at a time. The opposite cam in that control arm should be left tight.

1. Check & document initial alignment readings.
2. Raise vehicle underneath lower control arm.
3. Remove wheel.
4. Remove mounting bolt from upper shock mount, lower the shock for clearance.
5. Replace cam bolts as follows:
 - A. Mark position of cam.
 - B. Remove nut, washer and cam bolt.
 - C. Install lock washer & nut and tighten.
6. Repeat step 5 for the other cam assemblies.
7. Reinstall upper shock mount bolt and tighten.
8. Replace wheel and proceed with alignment.

